



MAST GUIDE BEARINGS

INTERCHANGE INFORMATION AND DIMENSIONS


SST Bearing No.	MRC Interchange	Hoover/NSK Interchange	BCA Interchange	McGill Interchange
MG206-2RS-1	206SZZ-16			
MG208-2RS-1	208SZZ-15		MG207FFH	BB1705
MG305-2RS-1	305SZZ-3	X421	MG305DD	BB849
MG305-2RS-2	305SZZ-6		MG305DDA	
MG305-2RS-3	305SZZ-7			BB1886
MG306-2RS-1	306SZZ-5	X555	MG306DD	
MG307-2RS-1	307SZZ-10	X376RS	MG307FFH	BB2005-2
MG307-2RS-2	307SZZ-9	X549RS	MG307FFK	
MG307-2RS-3	307SZZ-4		MG307FFA	BB816
MG307-2RS-4	307SZZ-18			
MG307-2RS-5	307SZZ-14			
MG308-2RS-1	308SZZ-5		MG308FFA	BB1747
MG308-2RS-3				
MG308-2RS-6	308SZZ-6			
MG309-2RS-1	309SZZ-4	X501RS	MG309DDA	BB1652
MG309-2RS-2	309SZZ-1	X469		BB850
MG309-2RS-3	309SZZ-5			
MG311-2RS-1	311SZZ-1			BB16493




MG206-2RS-1




MG208-2RS-1




MG305-2RS-1




MG305-2RS-2




MG305-2RS-3



MG306-2RS-1



MG307-2RS-1



MG307-2RS-2